

List of Figures

| | Page |
|--|------|
| Figure 2-1. <i>Using right-and left-hand diameter tapes</i> | 2-2 |
| Figure 2-2. <i>Tree calipers</i> | 2-3 |
| Figure 2-3. <i>Diameter tape measurement readings</i> | 2-3 |
| Figure 2-4. <i>Measuring DBH, normal tree</i> | 2-4 |
| Figure 2-5. <i>Measuring DBH, leaning tree</i> | 2-4 |
| Figure 2-6. <i>Measuring DBH, fork below 4.5 feet</i> | 2-4 |
| Figure 2-7. <i>Measuring DBH, fork above 4.5 feet</i> | 2-4 |
| Figure 2-8. <i>Correcting baseline distance</i> | 2-5 |
| Figure 2-9. <i>Measuring tree height, level and uphill</i> | 2-6 |
| Figure 2-10. <i>Measuring a leaning tree</i> | 2-7 |
| Figure 2-11. <i>Measuring forked-tree height (below 4.5 feet)</i> | 2-8 |
| Figure 2-12. <i>Measuring forked-tree height (above 4.5 feet)</i> | 2-8 |
| Figure 2-13. <i>Measuring tree heights by percentage method</i> | 2-8 |
| Figure 2-14. <i>Forked tree</i> | 2-14 |
| Figure 2-15. <i>Leaning tree</i> | 2-15 |
| Figure 2-16. <i>Downed tree</i> | 2-15 |
| Figure 4-1. <i>Topographic map with roads plotted</i> | 4-3 |
| Figure 4-2. <i>Culvert installation</i> | 4-6 |
| Figure 4-3. <i>Ditch-relief culvert</i> | 4-7 |
| Figure 4-4. <i>Open-top box culvert</i> | 4-7 |
| Figure 4-5. <i>Thank-you-ma'am</i> | 4-8 |
| Figure 4-6. <i>Development of switchbacks</i> | 4-9 |
| Figure 5-1. <i>Widow maker</i> | 5-1 |
| Figure 5-2. <i>Felling, herringbone pattern</i> | 5-2 |
| Figure 5-3. <i>Felling, tops toward the road</i> | 5-2 |
| Figure 5-4. <i>Clearing away small brush and saplings</i> | 5-3 |

| | Page |
|---|------|
| Figure 5-5. <i>The Humboldt undercut</i> | 5-3 |
| Figure 5-6. <i>Back cut</i> | 5-4 |
| Figure 5-7. <i>Cutting a tree in three places</i> | 5-5 |
| Figure 5-8. <i>Holding a corner</i> | 5-5 |
| Figure 5-9. <i>Barber chair</i> | 5-5 |
| Figure 5-10. <i>Methods to prevent splitting</i> | 5-6 |
| Figure 5-11. <i>Special chain-saw techniques</i> | 5-7 |
| Figure 5-12. <i>Tipping a tree with a truck jack</i> | 5-7 |
| Figure 5-13. <i>Cutting high to avoid rot</i> | 5-8 |
| Figure 5-14. <i>Sawing around rot</i> | 5-8 |
| Figure 6-1. <i>Bucking with a prop or a Dutchman</i> | 6-2 |
| Figure 6-2. <i>Log-bucking plan</i> | 6-2 |
| Figure 6-3. <i>Sample log-scale recording sheet</i> | 6-4 |
| Figure 6-4. <i>Log rules</i> | 6-6 |
| Figure 6-5. <i>Defects in logs</i> | 6-8 |
| Figure 7-1. <i>Choker and choker hooks</i> | 7-2 |
| Figure 7-2. <i>Choker hook rigging</i> | 7-2 |
| Figure 7-3. <i>Chains, tongs, and grabs for skidding logs</i> | 7-3 |
| Figure 7-4. <i>Double-deck skidway</i> | 7-5 |
| Figure 7-5. <i>Cross-haul method of loading logs</i> | 7-6 |
| Figure 7-6. <i>Knuckle-boom loader</i> | 7-6 |
| Figure 8-1. <i>Headsaw guide</i> | 8-1 |
| Figure 8-2. <i>Log-beam-type carriage</i> | 8-2 |
| Figure 8-3. <i>Headblock-type carriage</i> | 8-3 |
| Figure 8-4. <i>Fixed-post, manually operated dogs</i> | 8-4 |
| Figure 8-5. <i>Housing-post, manually operated dogs</i> | 8-5 |
| Figure 8-6. <i>Hammer dog</i> | 8-6 |

| | Page |
|---|------|
| Figure 8-7. <i>Boss dog</i> | 8-6 |
| Figure 8-8. <i>Lever-actuated networks</i> | 8-7 |
| Figure 8-9. <i>Power-actuated networks</i> | 8-7 |
| Figure 8-10. <i>Power receders</i> | 8-8 |
| Figure 8-11. <i>Indicators</i> | 8-8 |
| Figure 8-12. <i>Log faces and sawing procedures</i> | 8-13 |
| Figure 8-13. <i>Sawing oversized logs</i> | 8-19 |
| Figure 9-1. <i>Lumberyard layout</i> | 9-2 |
| Figure 9-2. <i>Lumber prop</i> | 9-2 |
| Figure 9-3. <i>Piling methods for rapid partial drying</i> | 9-3 |
| Figure 9-4. <i>Box piling</i> | 9-5 |