

**PREFACE**

This manual is a guide for Army repairers on aircraft rotor and power train maintenance. It includes descriptions, construction features, operating principles, elementary repair procedures, and basic repair shop allied subjects.

Rotor and power train information presented herein is general. For detailed information and specific repair procedures on a particular aircraft, refer to the technical manual for that aircraft or component.

The proponent of this publication is HQ TRADOC. Send comments and recommendations on DA Form 2028 (Recommended Changes to Publications and Blank Forms) directly to Assistant Commandant, US Army Aviation Logistics School, ATTN: ATSQ-LTD-L, Fort Eustis, Virginia 23604-5421.