

FIELD MANUAL
NO 1-514

HEADQUARTERS
DEPARTMENT OF THE ARMY
Washington, DC, 5 April 1991

**FUNDAMENTALS OF ROTOR AND POWER TRAIN MAINTENANCE –
TECHNIQUES AND PROCEDURES**

TABLE OF CONTENTS

	Page
PREFACE	iii
CHAPTER 1. PRINCIPLES OF HELICOPTER FLIGHT	
Aerodynamics	1-1
Bernoulli's Principle	1-2
Lift and Thrust	1-2
Airfoil Stability	1-3
Stress	1-3
Vibration	1-5
Nondestructive Inspection	1-5
CHAPTER 2. FUNDAMENTALS OF ROTORS	
Rotor System	2-1
Forces Acting on Rotors	2-1
Terminology	2-1
CHAPTER 3. ROTOR SYSTEM OPERATION	
Single and Tandem Rotors	3-1
Flight Controls	3-1
Main Rotor Head Assemblies	3-2
Tail Rotor Hubs	3-4
Main Rotor Blades	3-5
Tail Rotor Blades	3-11
CHAPTER 4. ALIGNMENT AND TRACKING PROCEDURES	
Main Rotor Blade Alignment	4-1
Unbalanced Semirigid Rotor Systems	4-1
Vertical Vibrations	4-2
Main Rotor Blade Tracking	4-3
Vibrex Balancing Kit	4-5
Preservation	4-10
CHAPTER 5. SINGLE-ROTOR POWER TRAIN SYSTEM	
Main Drive Shaft	5-1
Main Transmission	5-4

DISTRIBUTION RESTRICTION: Approved for public release; distribution is unlimited.

*This publication supersedes FM 55-414, 27 June 1984.

Main Rotor Mast Assembly 5-6
Tail Rotor Drive Shaft 5-6
Intermediate Gearbox 5-6
Tail Rotor Gearbox 5-6

CHAPTER 6. TANDEM-ROTOR POWER TRAIN SYSTEM

Engine Transmission 6-2
Engine-Combining Transmission 6-4
Forward Rotary-Wing Drive Transmission 6-4
Aft Rotary-Wing Drive Transmission 6-4
Drive Shafts 6-10

GLOSSARY

Abbreviations and Acronyms Glossary-1
Definitions Glossary-2

REFERENCES References-1

INDEX Index-1